

• Parallel: 8-bit data is transferred the same time

• Serial : 8-bit data is transferred one bit at a time

Serial data communication uses two methods:

Synchronous

Clock is transmitted with the data

Asynchronous

No clock is transmitted. Transmitter and receiver agree on the Clock speed for the data transmission (Baudrate)

UART

Universal Asynchronous Receiver/Transmitter

USART

Universal Synchronous Receiver/Transmitter

Duplex:

Data can be transmitted and received

Simplex:


Data can be transmitted only or received only. i.e. one direction only

Half Duplex:


Data can be transmitted in only one way at a time.

Full Duplex:

Data can be transmitted in both ways at a time.



In asynchronous transmission, each byte (character) is packed between *start* and *stop* bits.



- Baudrate
 Connection speed expressed in bits per second
- Stop Bit
 Number of stop bits transmitted, can be *one* or *two*
- Parity
 Indicates the parity mode, whether *odd* or *even*.
 Used for error checking.

- Mode
 Specifies whether RX or TX mode is enabled or disabled.
- Word Length Specifies the number of data bits transmitted or received. Can be 8-bits or 9-bits.
- Hardware Flow Control
 Specifies whether Hardware Flow Control is enabled or disabled.